




RAPTOR R

Front Assembly

Rear Assembly




Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

REV 230804-R05

RAPTOR R

Transmission Assembly



TRAXXAS

See Parts List for a complete listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

REV 230804-R05

Completed Assembly

RACTOR R

Body Assembly

This diagram illustrates the assembly of the Raptor R body. It shows the main body frame with a ribbed side panel. Two side rails, labeled 10121, are shown being attached to the top of the body. Two end caps, labeled 10144, are shown being attached to the ends of the side rails. Dashed lines indicate the alignment and placement of the components.




Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

REV 230804-R05



RAPTOR R

Chassis Assembly




Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

Driveshafts



Modular Assembly



Driveshaft Assembly