



WARNING!

Remove the AUX wire from the radio before connecting your ESC to Castle Link.*



*Failure to disconnect the AUX wire may result in damage to your Castle Link USB Adapter.



OVERPOWERING RC SINCE 1997™

castle™

A WORD ABOUT RECEIVER WIRES

- Connect RX wire (Brown/Red/Orange) to throttle channel (#2) on receiver.
- Connect AUX wire* (Brown/Red/White) to auxiliary/open channel on receiver.
- Connect the fan wire (Black/Red) to any open channel on the receiver.

*You MUST connect the AUX wire to an open channel on your receiver even if you are not utilizing the Auxiliary wire function. Failure to connect the AUX wire may limit the onboard BECs power capabilities. Auxiliary wire functions can be accessed via Castle Link.

NEW Quick Connect Duo - Allows you to connect to the Castle Link system without disconnecting your RX and AUX wire for easier, no hassle ESC tuning. The Quick Connect Duo (P/N 010-0149-00) is available from www.castlecreations.com or Castle Creations' resellers.



OVERPOWERING RC SINCE 1997™

castle™