


*Termik*




1.




Remove the supports by screwdriver

2.




3.



12x480mm

Medium CA

4.




10x295mm

Medium CA

L+R

5.



Activator

L+R

6.



prepared for the foil covering





7.

use covering film 38 mic with iron on 145°C





8.






L+R






17.

Thin CA




18.



Medium CA

20.


Medium CA



21.

use pliers for the 4mm nut

Medium CA




22.




23.

Medium CA




24.

be careful whether it is in the same line




25.



Medium CA


use pliers for the 4mm nut

26.




Medium CA

27.




28.



this hole to the tail

29.



put the servos in the fuselage

2nd  
1st


Thin CA

30.



all parts are ready for foil ironing

31.



do not leave the places that will be glued covered with foil


32.



higher horns put in the holes

Medium CA








**Medium CA**



The first step to glue the rudder to elevator  
The second step glue the tail to the fuselage




**Medium CA**



**Medium CA**




**Thin CA**




**Medium CA**

put the heatshrink!


41.




42.



43.




44.





45.




46.



47.





We wish you many happy flying hours with the Termik.

Your RC Factory team